French

Modèle : SM-504C

Souris Optique Sans Fil

MODE D'EMPLOI



ATTENTION : pour une utilisation correcte de cette souris, veuillez lire le mode d'emploi avant de procéder à l'installation.

French

Mise en place des piles

La souris sans-fil fonctionne avec deux piles AAA Ni-MH rechargeables

Mise en place des piles

Etape 1. Ouvrir le couvercle du compartiment à piles
Etape 2. Placer la pile comme indiqué à l'intérieur du compartiment
Etape 3. Replacer le couvercle



Connexion du Récepteur

En version USB+PS/2

Le récepteur est connecté à votre ordinateur par un câble USB 1.5m et un adaptateur USB+PS/2. Le câble peut donc être branché sur le port USB ou le port PS/2 de votre ordinateur.



Port USB

Port PS/2

Pour une installation en port PS/2
Attention : Eteindre l'ordinateur avant de brancher le câble au port PS/2. Brancher / débrancher des câbles d'un port PS/2 lorsque l'ordinateur est en marche peut endommager le port ou l'ordinateur.

1.Assurez-vous que l'ordinateur soit éteint.
2.Connecter l'adaptateur USB+PS/2 à la fiche USB du câble du récepteur. Ensuite connecter l'adaptateur au port souris PS/2 (vert) de l'ordinateur.



Installation en mode USB



Installation en mode USB+PS/2

En version USB

Le récepteur est connecté au port USB de votre ordinateur par un câble USB 1.5m.

Port USB



Installation en port USB

1.Connecter la prise USB au port USB de votre ordinateur.

Attention :
Windows 98 ou plus ou Macintosh OS 8.6 ou plus est nécessaire pour une installation en port USB. Connectez le câble du récepteur au port USB de votre ordinateur. Sous Windows, vous devrez peut-être insérer le CD du logiciel Windows. Insérez ce CD dans le lecteur CD-Rom de l'ordinateur lorsqu'il vous le demande. Puis suivez les instructions à l'écran.

Indicateurs sur le récepteur

Il y a deux indicateurs sur le récepteur.

1.Connect : le voyant clignote quand vous appuyez sur le bouton "Connect". Quand la souris est reconnue par le récepteur, ce voyant clignote rapidement.



2.En charge : Ce voyant s'allume quand le chargement est en cours et s'éteint quand la pile est complètement chargée.

Pour effectuer la reconnaissance entre le récepteur et la souris

Votre souris est livrée avec plusieurs codes permettant à votre récepteur de n'écouter qu'une seule souris. Procédez de la façon suivante avant la première utilisation et ensuite pour changer les codes si vous recevez des interférences indésirables d'une autre souris utilisée à proximité.

1. Appuyez sur le bouton CONNECT qui se trouve sur le devant du récepteur. Le voyant sur le récepteur clignotera régulièrement.
2. Appuyez sur le bouton CONNECT qui se trouve sur le dessous de la souris. Le voyant sur le récepteur clignotera rapidement.



A NOTER :

1. Le voyant LED reste allumé sans clignoter quand la reconn aissance est terminée.
2. Vous devez refaire cette procédure à chaque fois que vous changez les piles.

Charger la pile de la souris

Votre souris fonctionne avec deux piles AAA Ni-MH rechargeables. Avant utilisation, vous devez placer la souris sur son support afin de charger la pile pendant 12 heures. Ceci est très important pour la durée de vie de la pile. Assurez-vous que le voyant "CHARGE" soit allumé pendant cette période.

Si votre souris ne fonctionne pas normalement, chargez la pile en plaçant la souris sur son support.

ATTENTION : Certains ordinateurs coupent l'alimentation du port USB en mode veille, ce qui empêcherait la pile d'être chargée. Merci de garder votre ordinateur actif lorsque vous chargez la pile.

Installation du driver

Le driver est compatible avec Windows 98SE/ME/2000/XP/Vista
Le driver sera lancé automatiquement. Si ce n'est pas le cas, vous pouvez le lancer manuellement en double-cliquant sur le fichier setup.exe qui se trouve sur le CD-Rom.

Une icône représentant une souris apparaîtra sur la barre des tâches après installation du driver.

Icône souris

Double-cliquer sur cette icône pour paramétrer vos préférences pour l'utilisation de la souris.

Model:SM-504C

Wireless Optical Mouse

Instruction Manual

English



CAUTION: To use this device properly, please read the user's guide before installation.

FCC Compliance and Advisory Statement

Federal Communications Commission (FCC) Notice

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications, However, there is no guarantee that interference will not occur in particular installations. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient / Relocate the receiving antenna.

2.Increase the separation between the equipment and receiver.

3.Connect the equipment into an outlet on a circuit different from that the receiver is connected.

4.Consult the dealer or an experienced radio / TV technician for help.

CAUTION:

Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

English

Installing the Batteries

The Wireless mouse use two AAA NI-MH rechargeable batteries.

Installing Batteries in the Mouse

Step 1. Open the battery compartment

Step 2. Insert the batteries as shown inside the battery compartment.

Step 3. Replace the cover.



Connecting the Receiver

USB + PS/2 Version

The receiver is connected to your computer via a 1.5 meter USB + PS/2 dual Plug cable. And it plugs into your computer's USB port or PS/2 Port .

USB Port

PS/2 Port



For USB port Installation

1.Connect the USB plug ONLY to USB port of the computer.

For PS/2 mode Installation

CAUTION: Before installing the receiver's cable. Turn off your computer. Plugging and unplugging cables to your computer's mouse port while the computer is running can damage the mouse port or your computer.

1.Make sure that your computer is turned off.

2.Connect the USB to PS/2 Adaptor to USB plug. Then connect the adaotor to PS/2 mouse port (in Green color)



USB Mode Installation



USB + PS/2 Mode installation

English

USB version

The receiver is connected to your computer via a 1.5 meter USB cable ,and it plug to USB port of your computer.

USB Port



USB port Installation

1. Connect the USB plug to USB port of your computer.

CAUTION:

Windows 98 or higher or Macintosh OS 8.6 or higher is required for USB port installation. Connect the receiver cable to the USB port on computer. For Windows, you may be prompted to insert the Windows software CD. Insert this software CD into the computer's CD-ROM driver when asked to do so. Then follow the on-screen instructions.

Indicators on Receiver

There is two indicator on the Receiver.



1. Connect: the indicator will flash when you press the connect button. When the receiver successful change the ids, the indicator will flash several fast.
2. Charging: the indicator will light on when charging the battery in mouse, the indicator will turn off when the battery is full.

Changing the channel and security ID

Your mouse come with 1 Channel and multi security ID, Which can let receiver listen to one mouse, Do following step to change channel and security ID when you get undesired interference from another device used nearby.

1.Press the connect button on front of the receiver.
2.Press the connect button on the bottom of the mouse.

NOTE:

1.The indicating LED will light steadily when the synchronization linkage is completed.
2 You need to do above steps to re-connect the mouse each time you replace battery.
3.Your mouse may have only one channel due to different product version.

Charge the Battery in Mouse

Your mouse uses two AAA size NI-MH rechargeable batteries. Before you use the mouse, you need to place the mouse on the stand to charge the batteries for 12 hours. This is very important to battery life. Please make sure the charge indicator is light ON when you charge the mouse.

When you feel your wireless mouse is not working smoothly, that means that the batteries need to be recharged. Please put the mouse on the stand for charging. Normally it will take 12 hours to get the batteries fully charged.

USB charge Version

1.place the mouse one the stand and make sure the charging indicator is light ON.

CAUTION: Some computer will turn off the power of USB port when entering sleep mode. In this case, the battery inside the mouse can not be charged. So you are requested to keep your computer always ON When you charge the mouse

Software Installation

The driver supports Windows 98SE/ME/2000/XP/Vista.

The driver will install automatically if the auto-run is enable in your computer, otherwise, you can manually launch the installation by double clicking the file setup.exe in the CD-ROM.

The setup applets icon of the mouse will appear on the windows taskbar after successfully completing software installation.

Mouse setup applet

You can double click or right click the applet,and setup the functions of your preferred seledtion for mouse to enhance your device.

English